



NewQuay Apartments

Operation Instruction for Access Control System



Card Reader



Access Key



Remote Transmitter

Controlled Access Pedestrian Doors

Residents can gain access through their nominated doors upon presentation of a valid access key. Swipe access key in front of card reader. An accepted read, will unlock the doors for five second.

Access Controlled Vehicle Entry/Exit:

The Vehicle entry/access to Car Park is access controlled. Residents can gain access through the driveway gate by pressing 'button 1' on the hand held remote transmitter. Ensure that the gate has fully opened before proceeding. The driveway gate will close automatically after entering.

Care for your Access Key

Your Access key may get damaged if it is exposed to direct sunlight, placed near a magnetic source or submerged in water.

Care for your Remote Transmitter

Please ensure that your remote transmitter is not exposed to direct sunlight or submerged in water. The batteries in the unit should be replaced approx. every 24 months.

Revision: A