



17 VELLA DRIVE, SUNSHINE WEST VIC 3020

PH/FAX: 1300 812 746 **MOB:** 0412 327 087

EMAIL: INFO@STUDDCORP.COM.AU

ABN: 90 159 901 087 **ACN:** 159 901 087

SHOWERSCREEN MAINTENANCE

SHOWERSCREEN GLASS SHOULD BE CLEANED DAILY, OR AT LEAST WEEKLY TO REMOVE SOAP STAINS, WHICH IF LEFT UNCLENED, CAN ETCH, MARKING THE GLASS PERMANENTLY, AND POSSIBLY VOIDING THIS GUARANTEE. A PLASTIC SQUEEGEE IS USEFUL IN REMOVING WATER AND SOAP RESIDUE.

FRAMELESS SHOWERSCREENS

- CHECK HINGE AND CLAMP FITTINGS AT LEAST ONCE EVERY SIX MONTHS TO ENSURE SCREWS HAVE NOT BECOME LOOSE, AND THAT THE HINGES OPERATE SMOOTHLY.
- IT IS RECOMMENDED TO APPLY A COUPLE OF DROPS OF SEWING MACHINE OIL TO THE PIVOT PIN ON METAL HINGES EVERY SIX MONTHS.
- CHECK THAT THERE IS ADEQUATE CLEARANCE BETWEEN ALL GLASS EDGES AND THAT BUFFERS AND STOPS ARE INTACT. TOUGHENED GLASS
- TO CLEAN, LIGHTLY SPRAY THE FACE OF THE GLASS WITH A REPUTABLE BRAND OF GLASS CLEANER
- ALTERNATIVELY, ADD A FEW DROPS OF METHYLATED SPIRITS TO A CLEAN, NONABRASIVE DAMP CLOTH THEN WIPE THE GLASS. BUFF WITH A CLEAN LINT FREE CLOTH FOR A STREAK FREE FINISH.
- EUCALYPTUS OIL, ALLOWED TO PENETRATE, WILL ASSIST THE REMOVAL OF ADHESIVE LABELS.
- DIAMOND RINGS SHOULD NOT BE WORN WHEN CLEANING GLASS. TOUGHENED SAFETY GLASS IS SUBJECT TO BREAKAGE FROM SCRATCHES.
- A SINGLE EDGE SAFETY BLADE CAN BE USED WITH EXTREME CARE TO REMOVE LABELS AND SPILLAGES FROM GLASS. USE AT AN ACUTE ANGLE TO THE GLASS IN A SINGLE MOTION. DO NOT DRAW BACK OVER THE GLASS.

SHOWERSCREEN – ANODIZED ALUMINIUM FRAME

- ALUMINIUM FRAMES SHOULD BE WIPED WITH A CLEAN, NON-ABRASIVE DAMP CLOTH.
- OCCASIONAL USE OF A MILD DETERGENT AND WARM WATER SOLUTION MAY BE NECESSARY TO SHIFT STUBBORN DIRT AND STAINS.
- UNDER NO CIRCUMSTANCES USE SOLVENT OR HARSH DETERGENTS, BLEACH, SCOURERS OR ANY OTHER ABRASIVE CLEANER ON FRAME OR PLASTIC GLAZING BEADS. IF RESIDUE FROM GLASS CLEANING DOES COME IN CONTACT WITH THESE SURFACES RINSE IMMEDIATELY WITH CLEAN WARM WATER.

SHOWERSCREEN HARDWARE

- TO CLEAN HARDWARE SUCH AS HINGES AND JOINT CONNECTORS USE A MILD DETERGENT AND WARM WATER SOLUTION TO WIPE CLEAN. THEN RINSE WITH CLEAN WARM WATER.
- UNDER NO CIRCUMSTANCES USE SOLVENT OR HARSH DETERGENTS, BLEACH, SCOURERS OR ANY OTHER ABRASIVE CLEANER. FAILURE TO DO SO MAY VOID THE GUARANTEE.