


ICOM 4 HANDS-FREE APARTMENT STATION



URMET ICOM INTERCOM OPERATION



1. On approach the visitor touches the entry station screen and the code pad will appear. The resident then dials the apartment number on the code pad finishing with the 'bell' symbol, or alternatively, using the electronic directory, scroll for the apartment number using the arrow keys and then press the 'bell' symbol.



2. The video monitor inside the called apartment sounds an electronic tone and colour vision of the calling entry is displayed. The resident can answer by pressing the audio Hands-free button and two-way communication is established between the video monitor and the external entry station.



3. If the visitor is to be admitted, the resident presses the video monitor button with the key symbol, and the door/gate will be released

4. If lift control is present, the key button also enables the lift function.



5. The resident ends the conversation by pressing the audio Hands-free button. The video links will automatically time out.